

## **Procedure to Pair 2 Dog Systems**

**Models 502, 502A, 702, 702A, 802, 802A, 1202, 1202A, 302TS, 402TS, 802TS, 1202TS and all other Models**

### **Dog 1 Code Setting:**

- 1.) Turn on the Transmitter. (Either “M” or “C” Mode is okay)
- 2.) Rotate the intensity dial to “0”.
- 3.) Turn off the collar receiver for Dog 1. Position the Transmitter ON/OFF Magnetic Red Dot to the Collar Receiver ON/OFF Magnetic Red Dot more than 5 seconds until the Green LED on the Receiver blinks rapidly. For the 802TS and 1202TS hold the ON/OFF button for 5 seconds until the Green LED flashes.
- 4.) Press Dog 1 button first followed immediately by the Dog 2 button simultaneously holding both buttons until “Do-Me-So” sound is heard from the Receiver for confirmation.

### **Dog 2 Code Setting:**

- 1.) Turn on the Transmitter. (Either “M” or “C” Mode is okay).
- 2.) Rotate the intensity to “0”.
- 3.) Turn off the collar receiver. Position the Transmitter ON/OFF Magnetic Red Dot to Dog 2 Receiver ON/OFF Magnetic Red Dot more than 5 seconds until the Green LED on the Receiver blinks rapidly. For the 802TS and 1202TS hold the ON/OFF button for 5 seconds until the Green LED flashes.
- 4.) Press Dog 2 button first followed immediately by Dog 1 button simultaneously holding both buttons until “Do-Me-So” sound is heard from the Receiver for confirmation.

Notes:

If the Dog 1 or Dog 2 buttons are not pressed within 5 seconds, it is considered a normal power on process.

After successful code setting, existing code will be overwritten.

Do not hesitate to contact us at 1-260-357-0051 for help.