

PROCEDURE TO PAIR /SYNC SYSTEMS

Models: ET-300/302, ME-300/302, PG300302, ET-400/402, FT-330/332

Pairing dog one:

- 1.) Turn on the transmitter. Set M/C mode to “M” only. Rotate the intensity dial to 0 unlock if necessary.
- 2.) Turn off the collar receiver. Hold the red dot on transmitter to the red dot on receiver for more than 5 seconds until the green LED of receiver blinks rapidly, pull the two components away from each other.
- 3.) Press and hold the **Black S** button, do not let go, while holding press and hold the **Red S** button, until you hear the do-re-mi sound.

Pairing dog two:

- 4.) Repeat steps 1-2 above
- 5.) Press and hold the **Red S** button, do not let go, while holding press and hold the **Black S** button, until you hear the do-re-mi sound.

Models: FT-330/332

Pairing Wireless Finger Button (FT-030) to FT-330/332

- 1.) Turn on Finger Trainer Button (FT-030) Make sure the Transmitter is turned off (FT-330)
- 2.) Press and hold down the **Black** button on the Wireless Finger Trainer (FT-030), do not let go, then press and hold the **L** button to turn on the FT-330/332 Transmitter.
- 3.) Release the **Black** button on the Wireless Finger Trainer (FT-030) when transmitter is turned on and Ft flashes on the screen.
- 4.) Check for successful pairing by dialing to any number other than 0 and testing stimulation. (Collar receiver is not to be on the dog)

Models: ET-800/802, ET-1200/1202

Pairing dog one:

- 1.) Turn on the transmitter. Set M/C mode to “M” only. Rotate the intensity dial to 0 unlock if necessary.
- 2.) Turn off the collar receiver. Press and hold down the ON/OFF button of the receiver for more than 5 seconds until the green LED of the receiver blinks rapidly, release button.
- 3.) Press and hold the **Black S** button, do not let go. while holding press and hold the **Red S** button, until you hear the do-re-mi sound.

Pairing dog two:

- 4.) Repeat steps 1-2 above
- 5.) Press and hold the **Red S** button, do not let go, while holding press and hold the **Black S** button, until you hear the do-re-mi sound.

Models: FE-560/562, FE-580/582

Pairing dog one:

- 1.) Turn on the transmitter. Make sure you see the 1D on the screen. Dial the intensity dial to 0 unlock if necessary.
- 2.) Turn off the collar receiver. Hold the on/off button on the receiver for more than 5 seconds until the green LED of receiver blinks rapidly, then release.
- 3.) Press and hold the **■** button, while holding press and hold the **L** button, until you hear the do-re-mi sound.

Pairing dog two:

- 4.) Make sure you see the 2D on the screen. Repeat steps 1-3 above.

Please feel free to reach out to us at 1-260-357-0051 for assistance.
Thank you.

Models: EZ-900/902

Pairing dog one:

- 1.) Turn on the transmitter. Rotate the intensity dial to 00, unlock if necessary.
- 2.) Turn off the collar receiver. Hold the red dot on transmitter to the red dot on receiver for more than 5 seconds until the green LED of receiver blinks rapidly, pull the two components away from each other.
- 3.) Press and hold the **ON/OFF** button on the transmitter, do not let go, then press and hold the **S3 (Front Top Black)** button, until you hear the do-re-mi sound.

Pairing dog two:

- 4.) Repeat steps 1-2 above
- 5.) Press and hold the **ON/OFF** button on the transmitter, do not let go, then press and hold the **S4 (Front Bottom Red)** button, until you hear the do-re-mi sound.

Models: EZ-903/904

Pairing dog one:

- 1.) Turn on the transmitter. Rotate the intensity dial to 00, unlock if necessary.
- 2.) Turn off the collar receiver. Hold the red dot on transmitter to the red dot on receiver for more than 5 seconds until the green LED of receiver blinks rapidly, pull the two components away from each other.
- 3.) Press and hold the **ON/OFF** button on the transmitter, do not let go, then press and hold the **S1 (Top Left Orange)** button, until you hear the do-re-mi sound.

Pairing dog two:

- 4.) Repeat steps 1-2 above
- 5.) Press and hold the **ON/OFF** button on the transmitter, do not let go, then press and hold the **S2 (Bottom Left Yellow)** button, until you hear the do-re-mi sound.

Pairing dog three:

- 4.) Repeat steps 1-2 above
- 5.) Press and hold the **ON/OFF** button on the transmitter, do not let go, then press and hold the **S3 (Top Front Black)** button, until you hear the do-re-mi sound.

Pairing dog two:

- 4.) Repeat steps 1-2 above
- 5.) Press and hold the **ON/OFF** button on the transmitter, do not let go, then press and hold the **S4 (Top Front Red)** button, until you hear the do-re-mi sound.

Models: PE-900/902/903

Pairing dog one:

- 1.) Turn on the transmitter. Rotate the intensity dial to 00, unlock if necessary. Confirm that Multi Dog Mode Indicator is in 1 Dog Mode (1 should be showing on screen).
- 2.) Turn the collar receiver Off.
- 3.) Press the P button for more than 1 second until everything flashes to enter into Programming Mode.
- 4.) Press ON/OFF button four times to display Pr on screen.
- 5.) Hold the red dot on transmitter to the red dot on receiver for more than 5 seconds until the green LED of receiver blinks rapidly, pull the two components away from each other.
- 6.) Press the **S3 (Front Top Black)** button, until you hear the do-re-mi sound.
- 7.) Press P button to exit the Programming Mode.

Pairing dog two:

- 8.) Repeat steps 1-5 above Confirm that Multi Dog Mode Indicator is in 2 Dog Mode (1 2 should be showing on screen).
- 9.)
- 10.) Press the **S2 (Bottom Left Black)** button, until you hear the do-re-mi sound.
- 11.) Press P button to exit the Programming Mode.

Pairing dog three:

- 12.) Repeat steps 1-5 above Confirm that Multi Dog Mode Indicator is in 3 Dog Mode (1 2 3 should be showing on screen).
- 13.) Press the **S4 (Top Front Red)** button, until you hear the do-re-mi sound.
- 14.) Press P button to exit the Programming Mode.

Please feel free to reach out to us at 1-260-357-0051 for assistance.

Thank you.